

**User Manual for  
HITECH Micra 110**

# Contents

<b>1. Getting to know your phone.....</b>	<b>1</b>
Your Phone.....	1
Installing SIM card and battery.....	1
Installing Storage card.....	2
Battery charging.....	2
Power on/ off.....	2
Power on.....	2
Power off.....	2
<b>2. Using Call Function.....</b>	<b>2</b>
Making a call.....	2
Answering or rejecting a call.....	3
Answer a call.....	3
Reject a call.....	3
Adjusting call volume.....	3
Ending a call.....	3
<b>3. Contacts.....</b>	<b>3</b>
View a contact.....	3
Adding a new contact.....	3
<b>4. Message.....</b>	<b>3</b>
Write message.....	3
New SMS.....	3
New MMS.....	4
Inbox.....	4
Outbox.....	4
Drafts.....	4
Sentbox.....	4
Templates.....	4
Broadcast message.....	4
Voice mail server.....	4
<b>5. Call logs.....</b>	<b>4</b>
Missed calls.....	4
Dialed calls.....	4
Received calls.....	4
Rejected calls.....	5
Delete all.....	5
Call timers.....	5
GPRS counter.....	5

<b>6.Tools.....</b>	<b>5</b>
Internet.....	5
Input URL.....	5
Bookmarks.....	5
History.....	5
Offline pages.....	5
Calendar.....	6
Alarm.....	6
Calculator.....	6
World clock.....	6
Unit conversion.....	6
Ebook.....	6
Bluetooth.....	6
Flashlight.....	6
<b>7.Multimedia.....</b>	<b>7</b>
Camera.....	7
Video Rec.....	7
Image.....	7
Audio.....	7
Video.....	7
FM radio.....	7
Recorder.....	8
<b>8.My files.....</b>	<b>8</b>
<b>9.Games.....</b>	<b>8</b>
Snake,tetris.....	8
<b>10.HI LifeBox.....</b>	<b>8</b>
<b>11.Settings.....</b>	<b>8</b>
Dual SIM settings.....	8
Phone settings.....	8
Date & time.....	8
Profiles.....	9
Language settings.....	9
Profiles.....	9
Dedicated keys.....	9
Scheduled power on/off.....	9
Power management.....	9
Restore factory settings.....	9
Display settings.....	9

Wallpaper settings.....	9
Idle display settings.....	9
Brightness.....	9
Keypad backlight time.....	9
Security settings.....	10
Modify PIN2.....	10
Phone locked.....	11
Change phone password.....	11
Privacy.....	11
Auto keypad lock.....	11
Lock screen by end-key.....	11
Mobile tracker.....	11
Fixed dialing.....	12
Call settings.....	12
Call divert.....	12
Call waiting.....	12
Call barring.....	12
Hide ID.....	12
Others.....	12
Blacklist.....	13
Connections.....	13
<b>12.SAR.....</b>	<b>14</b>
<b>13. Important Notice.....</b>	<b>15</b>

## 1. Getting to know your phone

### Your Phone



### Installing SIM card and battery

- (1) Hold on **【End Key】** for about three seconds to switch off the phone.
- (2) Remove the battery cover.
- (3) Remove the battery.
- (4) Follow the sign for SIM1 and SIM2 on the phone to install SIM1 and SIM2. Please make sure that the golden contacts of the card face into the phone and the notched corner has the same direction with the card slot, then push the other side of the card gently until it fixes itself in the card slot.
- (5) Replace the battery with its golden contact part facing the set phone battery contact piece, and then replace the battery cover.

## **Installing Storage card**

- (1) Hold on **【End Key】** for about three seconds to switch off the phone.
- (2) Remove the battery cover.
- (3) Remove the battery.
- (4) Follow the arrow direction of "OPEN" on the T-Card slot cover, open card slot cover, put the T-Card into the slot vertically, make sure that the gold contacts of the card face upwards, until the card fixes itself in the card slot.
- (5) Follow the arrow direction of "LOCK" on the T-Card slot cover, pull card slot cover to lock the card slot.

## **Battery charging**

Charged by the travel charger

- (1) Install the battery correctly into the phone.
- (2) Insert the lead of the travel charger to connecting slot of the phone, and then connect the charger to a standard power socket.

When charging is complete, unplug the charger from the standard power socket first, and then disconnect the phone and charger.

## **Power on/ off**

### **Power on**

Hold on **【End Key】** for three seconds to switch on the phone.

### **Power off**

Hold on **【End Key】** for three seconds to switch off the phone.

## **2. Using Call Function**

### **Making a call**

- (1) On the Home Screen, input the area code and phone number.
- (2) Select **<Options→Call→Voice call→SIM1/SIM2>** to select SIM1 or SIM2 to call.

## **Answering or rejecting a call**

### **Answer a call**

When there is an incoming call, you can press **【Left Soft Key】** to answer.

### **Reject a call**

When there is an incoming call, you can press **【End Key】** to reject it.

### **Adjusting call volume**

During a call, you can press **【Up/Down Key】** to adjust the earphone volume.

### **Ending a call**

Press **【End Key】** to end the call.

## **3. Contacts**

### **View a contact**

Enter the phonebook, the phone is defaulted to show contact list with all entries.

### **Adding a new contact**

On the Contacts list, select<**Options**→**New**>to create a new contact.

- ❖ **Phone**: You can input the contact name, mobile phone, etc. You can also set special ring for the contact entry.
- ❖ **SIM1**: The input record will be saved to SIM1, with each name one phone number.
- ❖ **SIM2**: The input record will be saved to SIM2, with each name one phone number.

## **4. Message**

### **Write message**

#### **New SMS**

Enter the main menu and select [**Message**→**Write message**→**New SMS**] to edit a new SMS directly.

After writing an SMS, press **【OK Key】** to send the message.

## **New MMS**

Enter the main menu and select [**Message**→**Write message**→**New MMS**] to create a new MMS.

## **Inbox**

Store all received SMS and MMS.

## **Outbox**

Store all SMS and MMS failed to be sent.

## **Drafts**

Save edited SMS and MMS haven't sent.

## **Sentbox**

Store all the SMS and MMS successfully sent out.

## **Templates**

While editing messages, you can directly cite the preset common phrases. Select <**Edit**> to set the common phrases by yourselves.

## **Broadcast message**

You can receive broadcast text messages with various contents via network service, such as news, weather or traffic information. For more details, please consult your network operator.

## **Voice mail server**

This function works like an answering machine, which can transfer a missed call to your personal voice mail, allowing the caller to leave a voice message and notify you by an SMS. Voice Mail is a part of the bundled software provided by network operator, therefore, you need to register to active this function, and manually set the phone. Please contact with your network operator for more details.

## **5. Call logs**

### **Missed calls**

Display recent calls unpicked up.

### **Dialed calls**

Display recent calls dialed.

### **Received calls**



Display recent calls received.

### **Rejected calls**

Display recent calls rejected.

### **Delete all**

Delete all the call entries.

### **Call timers**

Select the desired SIM Card, and then you can view all relevant information about the SIM Card.

### **GPRS counter**

You can view the detail about GPRS flowrate.

## **6. Tools**

### **Internet**

#### **Input URL**

Enter the wanted website, and select<**OK**> to connect it.

Caution:

1. Your network service provider may not support some functions. In order to ensure the browser work normally, please confirm first that your SIM card supports and have the Internet function activated.
2. If you browse the web page, flowrate fee will be charged.

#### **Bookmarks**

Bookmarks are defaulted as blank, and you are able to edit it as you want. Save the common visited website into the Favorites, and marked by simple names. Select one saved name, then the corresponding web will be connected.

#### **History**

Record the websites you visited before.

#### **Offline pages**

After saving a website as snapshot, you can browse the website while offline.

## **Calendar**

Once you enter this menu, there is a monthly-view calendar for you to keep track of important appointments, etc.

## **Alarm**

On the Home Screen, press **【Left Soft Key】** to enter the main menu, and select **[Tools→Alarm]**, then you can set the alarm name, time, ring and mode.

## **Calculator**

Directly input numbers, press **【Navigation Key】** to select your desired operation symbols (+, -, /, X). Press **【OK Key】** to get the answer.

## **World clock**

This function allows you to check the standard time in different areas of the world.

## **Unit conversion**

This functionality enables you to convert values from one unit to another.

## **Ebook**

You can view file in TXT format by Ebook and copy the TXT file to the **[Ebook]** folder in the phone or memory card from your PC.

## **Bluetooth**

With Bluetooth, you can make a wireless connection to other compatible devices, such as mobile phones, headsets and car kits. You can use the Bluetooth to send images, video clips, music, sound clips and notes, and transfer files from your compatible pc.

## **FlashLight**

You can use this function to turn on/off the flashlight.

## **Facebook, Yahoo! And Twitter**

These applications enable you to get direct access to the respective sites.

## **Services**

This functionality includes STK options for the network providers.

## **7. Multimedia**

### **Camera**

Enter the main menu, and select [**Multimedia** → **Camera**] to enter the camera preview screen, press **【OK Key】** to take a photo.

### **Video Rec.**

Enter the main menu, and select [**Multimedia** → **Video Rec.**] to enter the video preview screen, and press **【OK Key】** to start recording the video.

### **Image**

The function provides a prompt access to view the photos and pictures.

### **Audio**

Enter the main menu, and select [**Multimedia** → **Audio**] to enter the Audio Player screen:

- ❖ Press **【OK Key】** to play or pause
- ❖ Press **【Left/Right Key】** to skip to last /next one
- ❖ Press **【Up/Down Key】** to adjust the playing volume

### **Video**

Enter the Main menu, and select [**Multimedia** → **Video**]. In the full screen:

- ❖ Press **【OK Key】** to play or pause
- ❖ Press **【Up/Down Key】** to skip to last /next one
- ❖ Press **【Left/Right Key】** to adjust the playing volume
- ❖ Press **【# Key】** to exit full screen

### **FM radio**

Enter the Main menu, then select [**Multimedia** → **FM radio**].

- ❖ Press **【OK Key】** to play or pause
- ❖ Press **【Left/Right Key】** to adjust the radio frequency.
- ❖ Press **【Up/Down Key】** to adjust the playing volume

## Recorder

Enter the main menu, select [**Multimedia**→**Recorder**], and press **【OK Key】** to start recording. After ceasing the recording, the recorded file will be automatically save in the folder [**Audio**].

## 8. My files

This menu allows you to manage files stored in the phone or storage card.

## 9. Games

### Snake, Tetris

These are two preloaded games.

## 10. HI LifeBox

An exclusive application only available in Hitech mobiles. You can get Bollywood updates, cricket score updates, astrology updates just at a single click.

## 11. Settings

### Dual SIM settings

- ❖ **Standby mode:** You can select the standby mode for SIM card, either to have one SIM card standby, or to have both SIM cards standby simultaneously.
- ❖ **Reply by master SIM:** You can activate the function to reply from current SIM card for call and SMS.
- ❖ **Set SIM name:** You can name the Card as you want.

### Phone settings

#### Date & time

- ❖ **Set time:** Directly input the time or press **【Up /Down Key】** to set it.
- ❖ **Set date:** Directly input the date or press **【Up /Down Key】** to set it.

## **Language settings**

You can select the language you want.

## **Profiles**

The mobile phone provides multiple user profiles, so that you can customize some settings to adapt to the specific events and environments.

Customize the user profiles according to your preference and then activate the user profiles. The user profiles fall into seven scenarios: **General, Silent, Meeting, Indoor, Outdoor, Earphone, Bluetooth.**

## **Dedicated keys**

You can change the responsible shortcuts for **【 Right Soft Key 】** and **【 Navigation Key 】** under standby mode.

## **Scheduled power on/off**

You can set the phone to switch on/off at a scheduled time.

## **Power management**

Display the battery capacity.

## **Restore factory settings**

Reset all parameter values into default status. Please enter the privacy preserving password (Initial password is 1234) to resume factory setting.

## **Display settings**

### **Wallpaper settings**

Select the default or other pictures as the wallpaper of the phone.

### **Idle display settings**

You can choose whether to display time and date, SIM1, SIM2 on the Home Screen.

### **Brightness**

Press **【 Left /Right Key 】** to adjust the brightness.

### **Keypad backlight time**

Select the desired keypad light time.

## **Security settings**

### **PIN**

PIN code is the personal identification number for SIM card. It never be modified, the initial password set by network operator should be 1234 or 0000. If activated the power-on PIN code, then you have to input the PIN password each time you switch the phone on. You can modify the PIN code to prevent your SIM card being used by others.

#### **Caution:**

If you input your PIN code incorrectly three times in succession, the SIM card will be locked automatically, and prompting to enter PUK code to unlock it. Therefore, please do remember the PIN code, if you modify it.

PUK code (PUK1) is made up by 8 digits, unmodifiable. When the phone is locked by PIN code, please enter correct PUK code to unlock the phone. If you incorrectly input the PUK code ten times in succession, then the SIM card cannot be used any more. Some PUK codes are provided together with the SIM card, some should be gained from the network service provider. If you don't know the PUK code while your PIN code is locked, please never input the code casually. In this case, please call the hotline of the service provider for your SIM card, after simply checking about the user identity, you can gain the PUK code for free to unlock your phone.

#### **Caution:**

Please be careful when use this function. If you forget PUK code, please consult your network operator. If you incorrectly input the PUK code ten times in succession, the SIM card will be scrap.

### **Modify PIN2**

PIN2 code is the personal identification code required for some certain functions (such as set fixed number, set phone fare, etc).

PIN2 code is another password provided together with SIM card by service provider. If wrongly input it for three times in succession, the phone will be locked until correct PUK2 code entered, for detailed operation, please refer to PIN code and PUK code.

### Caution:

If you incorrectly input the PUK2 code ten times in succession, you will not be able to use SIM card. Please be careful when use this function.

### Phone locked

After activated this function, you should input password each time you switch the phone on.

The defaulted password is "1234".

### Change phone password

You can change the phone password.

The defaulted password is "1234".

### Privacy

Secured by phone password, the phone will be protected from other unauthorized users. When password function has been activated for call logs or message, you have to enter correct password on corresponding main menu or sub-menu. The defaulted password is "1234".

### Auto keypad lock

After activating this function, the phone will be locked automatically if the time you set is arrived, so as to avoid error operations.

- ❖ **Manual lock keypad:** On the Home screen, press **【Left Soft Key】**, then press **【\* Key】** to lock the keypad manually.
- ❖ **Manual unlock keypad:** On the Home screen, press **【Left Soft Key】**, then press **【\* Key】** to unlock the keypad manually.

### Lock screen by end-key

Once activated this function, when the backlight is on, press **【End Key】** to turn off the backlight and auto lock the keypad.

### Mobile tracker

When the mobile tracker is on, once your SIM card is replaced, the phone will automatically send stolen information to the prior SIM card.

## Fixed dialing

### Call settings

#### Call divert

Based the set diverting conditions, incoming calls will be forwarded into voice mail or other numbers.

#### Call waiting (Need network support)

- ❖ **Activate:** If you set the function on, the network will alert you that there is an incoming call. You can keep current call and answer another one.
- ❖ **Cancel:** Cancel call waiting function, then the new incoming calls won't be answered while you're on the phone already.
- ❖ **Check status:** Select it to view current status of this function.

#### Call barring

This function helps you to restrict the incoming and outgoing calls.

Caution:

1. Some network operators forbid the function. For more details, please contact your network service provider.
2. The network operator will provide you the initial network password while you apply for this service.

#### Hide ID (Need network support)

- ❖ **Hide ID:** While calling, the recipient won't see your phone number.
- ❖ **Display own ID:** While calling, your phone number will be visible for the recipient.
- ❖ **Display ID by network:** While calling, whether your phone number will be visible or not for the receiver depends on the network presetting.

#### Others

- ❖ **Call time minute reminder**

If you activate the function, an elapsed time reminder will be heard at the set second of every minute during your call, so that you may end the call timely to save the phone fare.



### ❖ **Auto redial**

If you set this function on, the phone will redial the number after an unsuccessful call.

### ❖ **Vibration when connected**

The phone will vibrate to prompt you when the recipient answers your phone.

### ❖ **Reply SMS after reject**

You can select whether to reply an SMS after rejecting a call.

### ❖ **Auto Call Record**

To record the call automatically.

### **Blacklist**

He or she can't call you or send message to you if you set the blacklist status to on and add his or her number to blacklist.

### **Connections**

Through this function, you can select network and set preferred network.

## **Specific Absorption Rate**

Mobile device is a radio transmitter and receiver. It is designed to not exceed the limits for exposure to radio waves recommended by various governments. In India, these guidelines were developed by the Government of India, Department of Telecommunications, Ministry of Communications and IT and include safety margins design to assure the protection of all persons, regardless of age and health, and to account for any variations in measurements.

The guidelines use a unit of measurement known as the Specific Absorption Rate (SAR).

SAR level for mobile handsets Shall be limited to 1.6 Watt/kg, averaged over a 6 minutes period and taken over a volume containing a mass of 1 gram of Human tissue OR 2.0 W/Kg averaged over 10 gram tissue.

### **Highest SAR Value for Micra 110 as below-**

When tested on head -1.197Watt/Kg

When tested on body -0.545Watt/Kg

## **Important Notice**

### **COPYRIGHT NOTICE**

*Copyright © 2014, Hitech Cellphones Pvt. Ltd. all rights reserved.*

### **TRADEMARKS**

Hitech Cellphones Pvt. Ltd. and Hitech logos are trademarks or registered trademarks of Hitech Corporation. Other companies and product names mentioned herein may be trademarks or trade names of their respective owners, and the mention is subject to compulsory citation purpose.

### **WARRANTY DISCLAIMER**

Hitech Cellphones Pvt. Ltd. makes no representations or warranties, either expressed or implied, by or with respect to anything in this document, and shall not be liable for any implied warranties of merchantability or fitness for a particular purpose or for any indirect, special or consequential damages.

### **CONFIDENTIALITY STATEMENT**

The contents of this document (including any accessory) are confidential. The receiver should be aware of the confidentiality of the document and will neither use it for any other purpose except for the purposes specified nor disclose the document to any third party.